













## INSTRUCTIONS FOR UNEVEN COATING

Uneven coating on the glue roller could indicate that the scraper blade is out of adjustment. To adjust the scraper blade do the following:

1. Shut off the motor and remove plug from power source.
2. Turn coating dial to zero.
3. Check that the setscrew holding the yoke to the scraper bridge pin is tight.
4. Remove feed table.
5. Loosen scraper blade screws and remove scraper.
6. Inspect scraper blade to see if it is in good condition, no damage to the blade.
7. Reattach scraper blade the same way it was removed. (Short side facing glue roller.)
8. Snug up on screws and insert shims between blade and glue roll. (Shim stock of .001 is recommended.)
9. Tighten screws. (Remove shims.)
10. The gap between scraper and glue roll will now be even.

GENERAL TOOLS FOR REPAIR & MAINTENANCE OF THE LP SERIES LABEL PASTER

NOMINAL HEX KEY SIZES (ALLEN WRENCH)

1/16, 5/64, 3/32, 1/8, 5/32

OPTIONAL

.001" SHIM STOCK OR PIECE OF BOND PAPER  
(3) PIECES APPROXIMATELY 4" LONG

Pro Pack Solutions, Inc.  
2421B Lance Court  
Loganville, GA 30052  
Ph: (877) 776-7225  
[www.ProPackSolutions.com](http://www.ProPackSolutions.com)





CONNECTING DIAGRAM FOR MOTOR WITH ON/OFF SWITCH FOR  
LP SERIES LABEL PASTER

